



NOTES:

1. THE CURB'S TOP WOOD NAILER, AND SEAL STRIP ARE TO BE SUPPLIED BY THE CURB MANUFACTURER.
2. ATTACH NAILER TO DECK WITH SUITABLE FASTENERS.
3. WHEN POSSIBLE, THE MECHANICAL UNITS SHOULD NOT BE SET UNTIL THE ROOF MEMBRANE AND FLASHING HAVE BEEN INSTALLED.

NOTES:

1. THIS DETAIL SHOULD BE USED ONLY WHERE THE DECK IS SUPPORTED BY THE WALL.
2. THE JOINTS IN THE SHEET METAL COUNTERFLASHING SHOULD NOT BE SOLDERED.
3. ATTACH NAILER TO WALL WITH SUITABLE FASTENERS.
4. FREQUENT NAILING OF SHEET METAL FLANGE IS NECESSARY TO MINIMIZE THERMAL MOVEMENT.

TITLE	
Curb Flashing	
Name	
Detail No. CTR-608	
Drawn By:	Reviewed BY:
JA	KF
Applicable to all Flex CTR Roof Systems	
FLEX MEMBRANE INTERNATIONAL	2670 Leiscz's Bridge Rd. Leesport, PA 19533 800-969-0108 www.flexmembranes.com