



Notes

1. An area divider is designed simply as a framed member attached to a properly flashed wood base plate that is anchored to the roof deck. Area dividers are not required to eliminate membrane stresses but are often used as terminations where reroofing is involved.
2. The air/vapor barrier membrane should be installed under the divider when the divider is installed. This may involve the coordination of rough carpentry and roofing. Overlap 3" on each side of the air/vapor barrier.
3. Sheathing at deck level is optional. Refer to local codes.
4. Priming is required with all self-adhered membranes.

Flex SBS Modified Roofing Systems

AREA DIVIDER

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 08/07

Revision: KF

FLMB-13E02

Flex Membrane International, Inc.
 2670 Leisch's Bridge Rd. Suite 400
 Leesport, PA 19533
 800-969-0108
 www.flexmembranes.com