



Notes:

- 1) The air/vapor barrier membrane may be a Flex Modified Membrane.
- 2) The base sheet or ply sheet should extend 2" over the cant on the vertical wall to ensure edge is sealed.

Flex SBS Modified Roof Systems

PARAPET DETAIL

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Date: 8/07

Revision: KF

FLMB-2E02

Flex Membrane International, Inc.
2670 Leisch's Bridge Rd.
Suite 400
Leesport, PA 19533
800- 969-0108
www.flexmembranes.com