



Notes

1. Fasten cant strip solidly to wood blocking using mechanical fasteners.
2. Extend the base flashing sheet down the outside face beyond wood blocking and fasten at 8" o.c.

Flex SBS Modified Roofing Systems

**CANTED
 ROOF EDGE**

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 08/07

Revision: KF

FLMB-6E02

Flex Membrane International, Inc.
 2670 Leisch's Bridge Rd. Suite 400
 Leesport, PA 19533
 800-969-0108
 www.flexmembranes.com