



Notes

1. The membranes should be mechanically clamped by the drain assembly.
2. A minimum slope of 1:50 (1/4":12') to drain is recommended.
3. Drainage in the immediate area around the drain may be facilitated by tapering the insulation and incorporating a sump.
4. Position target sheet 45 degrees to the base sheet. Use a full width sheet cut square, 39" x 39".
5. Drain designs vary. Always refer to drain manufacturer's recommendations.

Flex SBS Modified Roofing Systems

ROOF DRAIN

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 08/07

Revision:KF

FLMB-8E02

Flex Membrane International, Inc.
2670 Leisch's Bridge Rd. Suite 400
Leesport, PA 19533
800-969-0108
www.flexmembranes.com