



REROOFING NOTE:
 ANGLE AT VENT PIPE/ROOF INTERSECTION SHALL BE 90 DEGREES. ... IF METAL COLLAR EXISTS FROM BUR, REMOVE IT PRIOR TO INSTALLATION OF MEMBRANE. COVER ANY ASPHALT RESIDUE ON PIPE WITH ALUMINUM TAPE PRIOR TO INSTALLATION OF MEMBRANE.

| | | | |
|-------------------------------|----|--|---------|
| TITLE | | FIELD FLASHED VENT PIPE | |
| NAME | | DETAIL NO. 4.50 | |
| DRAWN BY: | KF | DATE: | 10/2009 |
| APPLICABLE TO ALL FLEX PVC | | | |
| MECHANICALLY FASTENED SYSTEMS | | | |
| FLEX MEMBRANE INTERNATIONAL | | 2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com | |