



## **FLEX TPO INSIDE/OUTSIDE CORNERS**

### **PRODUCT DESCRIPTION**

Flex TPO Inside/Outside Corners are pre-molded and are used for flashing inside/outside corners on a variety of details. Installation is fast and easy with no cutting or stretching required.

### **PHYSICAL PROPERTIES**

Thickness:	60-mil
Color:	White, Gray and Tan

### **INSTALLATION**

1. Begin welding at the innermost corner point and work away from the corner.
2. Use a lower temperature setting on the heat welder than when welding reinforced TPO membrane. (Typically a setting of 660 on a scale of 100 is appropriate for welding Flex TPO Inside/Outside Corners).
3. Use the edge of the roller to crease the corner flashing into any membrane step-off to create a proper seal.

### **CAUTIONS AND WARNINGS**

Store Flex TPO Inside/Outside Corners in a cool, shaded area and cover with light-colored, breathable, waterproof tarpaulins. Flex TPO Inside/Outside Corners or TPO membrane that has been exposed to the weather for approximately 7 days or longer prior to use must be prepared with Flex Weathered Membrane Cleaner prior to hot air welding.