



NOTE:
 PRESSURE TREATED WOOD BLOCKING MUST BE
 IMBEDDED IN LAYER OF FLEX APPROVED
 SEALANT PRIOR TO FLASHING.

FLEX MECHANICALLY FASTENED SYSTEMS
 REQUIRE FLEX SCREWS AND PLATES 12" O.C.
 AROUND THE BASE OF THE BEAM.

TITLE	I-BEAM FLASHING DETAIL	
NAME	DETAIL NO. 4.20	
DRAWN BY:	SK	DATE: 8/2012
APPLICABLE TO ALL FLEX		
MECHANICALLY FASTENED SYSTEMS		
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com	