



REROOFING NOTE:
 ANGLE AT VENT PIPE/ROOF INTERSECTION SHALL BE 90 DEGREES. IF METAL COLLAR EXISTS FROM BUR REMOVE IT PRIOR TO INSTALLATION OF MEMBRANE. COVER ANY ASPHALT RESIDUE ON PIPE WITH ALUMINUM TAPE PRIOR TO INSTALLATION OF MEMBRANE.

TITLE		FIELD FLASHED VENT PIPE	
NAME		DETAIL NO. 4.50	
DRAWN BY:	DATE:	SK	8/2012
APPLICABLE TO FLEX			
MECHANICALLY FASTENED SYSTEMS			
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com		