



NOTES:

- 1) NAILERS SHALL BE SECURELY ANCHORED TO THE DECK TO RESIST A FORCE OF 100 POUNDS PER LINEAL FOOT IN ANY DIRECTION.
- 2) FOLLOW EXISTING SINGLE-PLY MFG. RECOMMENDATIONS FOR TIE-IN DETAIL AND FOR CLEANING MEMBRANE.
- 3) CLEAN EXISTING SINGLE-PLY MEMBRANE PRIOR TO HOT-AIR WELDING.

TITLE	TIE IN TO EXISTING SINGLE PLY	
NAME	DETAIL NO. 3.91	
DRAWN BY:	SK	DATE: 8/2012
APPLICABLE TO ALL FLEX MECHANICALLY FASTENED SYSTEMS		
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com	