



NOTES:

1. REFER TO FLEX MEMBRANE SPECIFICATIONS FOR PRODUCT DATA SHEETS FOR APPROPRIATE BEAD SPACING BASED UPON THE BUILDING HEIGHT, WARRANTY TERM AND ACCEPTABLE SUBSTRATE.
2. THE SURFACE TO WHICH ADHESIVE IS TO BE APPLIED SHALL BE DRY, FREE OF DUST, PROTRUSIONS, SHARP EDGES, LOOSE AND FOREIGN MATERIALS, OIL AND GREASE. AREA SHOULD BE CLEANED WITH AN AIR BLOWER.
3. PREVIOUSLY UNEXPOSED ASPHALT OR RESIDUE MUST BE PRIMED
4. SEAL ALL GAPS IN THE CONCRETE DECK TO AVOID CONDENSATION ISSUES OR FILL WITH FLEX INSULATION ADHESIVE.
5. AT THE BEGINNING OF THE INSULATION ATTACHMENT PROCESS AND PERIODICALLY THROUGHOUT THE DAY, CHECK THE ADHESION OF BOARDS TO ENSURE A TIGHT BOND IS CREATED AND MAXIMUM CONTACT IS ACHIEVED.
6. ALL BOARDS SHOULD BE WEIGHED DOWN AND SLIT TO CONFORM TO THE CONTOURS OF THE SUBSTRATE.

TITLE	
INSULATION ADHESIVE ROW SPACING	
NAME	
DETAIL NO. 6.30	
DRAWN BY:	DATE:
SK	12/2013
APPLICABLE TO ALL FLEX	
ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com