



- NOTES:
- 1) ALL FLASHINGS MUST BE A MIN. HEIGHT OF 8" ABOVE THE FIELD MEMBRANE.
  - 2) ALL FLASHING MEMBRANE THAT IS INSTALLED HIGHER THAN 18" VERTICAL MUST BE ADHERED TO SUBSTRATE.
  - 3) FLEX CUT EDGE SEALANT IS REQUIRED AT ALL NON FACTORY CUT EDGES

TITLE CURB FLASHING-REMOVABLE UNIT	
NAME DETAIL NO. 3.30	
DRAWN BY: SK	DATE: 5/2017
APPLICABLE TO ALL FLEX TPO	
ADHERED ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com