



NOTES:

1. WOOD NAILER MUST EXTEND PAST TOTAL WIDTH OF DECK FLANGE.
2. INSTALL WALL FLASHING PRIOR TO SCUPPER INSTALLATION.
3. ALL JOINTS IN FLEX TPO PLUS COATED METAL MUST BE OVERLAID WITH FLEX FLASHING.
4. WATER CUT-OFF MASTIC UNDER SCUPPER FLANGE MUST BE UNDER CONSTANT COMPRESSION.
5. MINIMUM 2" (50 mm) SPLICE FROM NAIL HEAD.
6. FLEX SEALANT IS REQUIRED AT FLASHING EDGE ON SCUPPER EDGE.

TITLE	
THROUGH WALL SCUPPER	
NAME	
DETAIL NO. 5.50	
DRAWN BY:	DATE:
SK	8/2012
APPLICABLE TO ALL FLEX	
TPO ADHERED SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com