



NOTES:

- 1) NAILERS SHALL BE SECURELY ANCHORED TO THE DECK TO RESIST A FORCE OF 100 POUNDS PER LINEAL FOOT IN ANY DIRECTION.
- 2) FOLLOW EXISTING SINGLE-PLY MFG. RECOMMENDATIONS FOR TIE-IN DETAIL AND RECOMMENDATION FOR CLEANING MEMBRANE.
- 3) CLEAN EXISTING SINGLE-PLY MEMBRANE PRIOR TO HOT-AIR WELDING.

TITLE		TIE IN TO EXISTING SINGLE PLY
NAME		DETAIL NO. 3.91
DRAWN BY:	SK	DATE: 1/2017
APPLICABLE TO ALL FLEX		
ADHERED ROOFING SYSTEMS		
FLEX MEMBRANE INTERNATIONAL		2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com