



NOTES:

LOCATE FLEX TERMINATION A MINIMUM OF 8" IN VERTICAL HEIGHT FROM FIELD MEMBRANE.

1. POSITION THE FLEX ISOWELD PLATE 3 1/2"-4" FROM THE VERTICAL TRANSITION
2. FLEX ISOWELD IS NOT FOR USE WITH NON-FACED EPS OR XPS INSULATION

TITLE ISOWELD PARAPET CURB FLASHING	
NAME DETAIL NO. I-4	
DRAWN BY: SK	DATE: 8/2015
APPLICABLE TO ALL FLEX ISOWELD ATTACHED ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com