

NOTES:

1) FLEX MECHANICALLY ATTACHED SYSTEMS REQUIRE A MIN. OF 4 FLEX PLATE AND FASTENERS ASSEMBLIES AROUND THE BASE OF THE PENETRATION

- 2) PRESSURE TREATED WOOD BLOCKING MUST BE IMBEDDED IN A LAYER OF FLEX APPROVED SEALANT PRIOR TO FLASHING
- 3) SEALANT IS A MAINTENANCE ITEM. MAINTENANCE ITEMS ARE NOT INCLUDED IN THE FLEX WARRANTY
- 4) FLEX TPD: FLEX TPD CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPD

	ANGLE IRON FLASHING	
DETAIL NO. 4.10		4.10
	DRAWN BY: SK	2/2018
	APPLICABLE	TO ALL FLEX
	MECHANICALLY	ATTACHED SYSTEMS
	FLEX MEMBRANE	2670 LEISCZ'S BRIDGE RD. LEESPURT, PA 19533 800-969-0108

FlexRoofingSystems.com

INTERNATIONAL