



NOTES:

- 1) ALL FLASHINGS MUST BE A MIN. HEIGHT OF 8" ABOVE THE FIELD MEMBRANE.
- 2) ALL FLASHING MEMBRANE THAT IS INSTALLED HIGHER THAN 18" VERTICAL MUST BE ADHERED TO SUBSTRATE.
- 3) FLEX TPO: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE WALL FLASHING OVER 4' HEIGHT ALTERNATE METHOD	
NAME DETAIL NO. 2.50	
DRAWN BY: SK	DATE: 2/2018
APPLICABLE TO ALL FLEX	
MECHANICALLY ATTACHED SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com