



**NOTES:**

- 1) SEALANT IS A TWO STEP APPLICATION:
  - A) BEHIND TOP OF FLEX FLASHING.
  - B) TOP OF FLEX TERM BAR.
- 2) SEALANT SHALL BE APPLIED TO CLEAN AND DRY APPROVED SUBSTRATES.
- 3) FLEX TERM BAR SHALL BE SECURELY ANCHORED WITH GROMMETTED FASTENERS AND PROVIDE ADEQUATE COMPRESSION OF MEMBRANE FLASHING AND SEALANT.
- 4) ALL FLASHING MEMBRANE THAT IS INSTALLED HIGHER THAN 18" VERTICAL MUST BE ADHERED TO SUBSTRATE.
- 5) IF FLASHING HEIGHT IS HIGHER THAN 48" PLEASE REFER TO FLEX DETAIL 2.40.
- 6) FLEX TPO: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

8IN. MIN. 48IN. MAX

TITLE WALL FLASHING WITH SURFACE MOUNTED REGLET	
NAME DETAIL NO. 2.10	
DRAWN BY: SK	DATE: 2/2018
APPLICABLE TO ALL FLEX	
MECHANICALLY ATTACHED SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com