



NOTES:

- 1) ALL FLASHINGS MUST BE A MIN. HEIGHT OF 8" ABOVE THE FIELD MEMBRANE.
- 2) EXISTING COUNTERFLASHING IS ACCEPTABLE IF ABOVE MAXIMUM FLOOD LEVEL AND METAL IS IN GOOD CONDITION.
- 3) FUNCTIONAL WEEP HOLE MUST NOT BE BLOCKED
- 4) ALL FLASHING MEMBRANE THAT IS INSTALLED HIGHER THAN 18" VERTICAL MUST BE ADHERED TO SUBSTRATE.
- 5) IF FLASHING HEIGHT IS HIGHER THAN 48" PLEASE REFER TO FLEX DETAIL 2.40.
- 6) FLEX TPO: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE	WALL FLASHING CUT IN REGLET	
NAME	DETAIL NO. 2.20	
DRAWN BY:	SK	DATE: 2/2018
APPLICABLE TO ALL FLEX		
MECHANICALLY ATTACHED SYSTEMS		
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com	