



NOTES:

1) INSTALL FAN FOLD COVER BOARD WITH CONTINUOUS SIDE JOINTS AND END JOINTS STAGGERED A MIN. OF 12" FROM END JOINTS OF ADJACENT ROWS.

2) FAN FOLD COVER BOARD SHALL ABUT TIGHTLY AGAINST ADJACENT BOARDS.

3) IF FAN FOLD COVER BOARD IS BEING INSTALLED OVER AN EXISTING INSULATION BOARD ALL JOINTS MUST BE OFFSET A MIN. OF 6" BETWEEN LAYERS.

4) FASTENERS SHOULD NEVER BE CLOSER THAN 6" FROM THE EDGES OF OF THE BOARD.

5) DO NOT OVER DRIVE OR UNDER DRIVE THE FASTENER AND PLATE ASSEMBLY.

TITLE		FLEX FAN FOLD BOARD ATTACHMENT
NAME:		DETAIL 6.26
DRAWN BY:	MG	DATE:
		5/31/2023
APPLICABLE TO MECHANICALLY ATTACHED		
FLEX ROOFING SYSTEMS		
FLEX MEMBRANE INTERNATIONAL	5103A POTTSVILLE PIKE READING, PA 19605 800-969-0108 FLEXROOFINGSYSTEMS.COM	