



NOTES:

- 1) PRESSURE TREATED WOOD BLOCKING MUST BE IMBEDDED IN LAYER OF FLEX APPROVED SEALANT PRIOR TO FLASHING
- 2) A MIN. OF 4 FLEX PLATE AND FASTENER ASSEMBLIES ARE REQUIRED TO BE FASTENED AROUND THE BASE OF THE PENETRATION
- 3) FLEX TPO: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE	ANGLE IRON FLASHING DETAIL	
NAME	DETAIL NO. 4.10	
DRAWN BY:	SK	DATE: 2/2018
APPLICABLE TO ALL FLEX		
ADHERED ROOFING SYSTEMS		
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com	