



NOTES:

- 1) EXISTING DRAIN BOWL, CLAMPING RING AND DRAIN ACCESSORIES ARE TO BE CLEANED FREE OF ALL CONTAMINATES.
- 2) INTENDED FOR USE WITH STEEP SLOPE DRAIN SUMPS THAT ARE 1:12 SLOPE OR GREATER
- 3) FLEX MEMBRANE PLATES AND FASTENERS ARE REQUIRED TO BE INSTALLED 12" OC AROUND THE ROOF DRAIN
- 4) FLEX TPO: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE	
FLEX STEEP SLOPE DRAIN DETAIL	
NAME	
DETAIL NO. 4.32	
DRAWN BY:	DATE:
SK	11/2017
APPLICABLE TO FLEX	
ADHERED ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com